


ECT2 Touch Panel (CT)




Manual

www.ltech-led.com

System Diagram

LTECH



Product Features



- Powered by 100-240Vac wide voltage, no external power needed.
- RF+0-10V (2ch output) control modes, allowing more flexible and convenient applications.
- Work with 0-10V tunable white LED drivers. Dimming does not change CT, and CT adjustment does not affect brightness.
- · Use the capacitive touch panel with armored glass surface.
- · Install in 86 type or EU style junction boxes.
- Work with F series, Q series remotes to gain easy control.
- Work with the L-BUS gateway (WIFI-108) to achieve APP remote control over scenes.

			~	
	hni	COL	Sr	ecs
IECI		caι		


Model	ECT2 Touch Panel	
Control Type	Dim / CT	
Wireless Signal	RF 2.4GHz	
Input Voltage	100-240Vac	
Output Signal	0-10V×2	
Output Current	15mA×2 Channel	
Power Consumption	1W	
Working Temp.	-20°C~55°C	
Dimensions	86×86×36mm (LxWxH)	
Package Size	113×12×50mm (LxWxH)	
Weight(G.W.)	225g	

FC CE ROHS SELV

Product Size


LTECH

Unit: mm




Key Functions

When blue indicator light of \bigcirc key is on, long press \odot to turn on/off buzzer. When white indicator light of \bigcirc key is on, long press \bigcirc to match code.





Terminals





Wiring Diagram







RF Wireless Wiring

LTECH

Single Zone Control



Multiple Zone Control



* Touch panels can be sync controlled by multi remotes, please refer to the manual of remote's usage.

Match Code between Touch Panel & Remote

1. Long press ① on touch panel until indicator lights flash. Please proceed to the next step within 15 seconds.



2. Match code with F series remote:

Single zone remote: long press ON/OFF key on remote, the indicator light stops flashing, match code successfully.

Multi-zone remote: long press the matching zone's ON & OFF keys simultaneously, the indicator light stops flashing, match code successfully.




 Match code with Q series remote: long press the matching zone's "ON" key on remote, the indicator lights of touch panel stop flashing, match successfully.

ECT2 touch panel match with F2/F6 remote. ECT2 touch panel match with Q2 remote.



Match Code between Touch Panel & Gateway

 Long press ① on touch panel until indicator lights flash.



 Turn on L-BUS APP, enter "Zone Set" interface, click the right top "MATCH" key, then operate the following prompts.





Clear Code

Long press the scene key 1 and scene key 4 on the panel, the indicator light flashes several times, clear code successfully. Please clear the code when the touch panel switch indicator is white.



* This manual is subject to changes without further notice. Product functions depend on the goods. Please feel free to contact our official distributors if you have any question.

Warranty Agreement



- Warranty periods from the date of delivery 5 years
- Free repair or replacement services for quality problems are provided within warranty periods.

Warranty exclusions below:

- · Beyond warranty periods.
- Any artificial damage caused by high voltage, overload, or improper operations.
- Products with severe physical damage.
- Damage caused by natural disasters and force majeure.
- Warranty labels and barcodes have been damaged.
- No any contract signed by LTECH.
- Repair or replacement provided is the only remedy for customers. LTECH is not liable for any incidental or consequential damage unless it is within the law.
- LTECH has the right to amend or adjust the terms of this warranty, and release in written form shall prevail.